

CM2015PV Instructions

CM2015PV Constant Monitor Verification Tool

The CM1600, CM1601, CM1602, CM2815, CM2800 ESD constant monitors are factory calibrated and it is recommended to verify calibration with the CM2015PV periodic verification. The following procedure will verify wrist strap and work surfaces. Please note that some models of the Ranger Series Constant Monitors has adjustable alarm limits. The procedure is for the default settings. Not all models monitor work surfaces, and you may skip that procedure.

Wrist Strap Verification Procedure

- 1. Plug the CM2015PV's main lead (Male Phono Plug) to the OP1 remote of the workstation monitor.
- 2. To verify that the constant monitor's resistance limits, turn the dial of the CM2015PV to each designated resistance in Table 1 below and record the constant monitor reaction. If the resistance of the wrist strap is less than 1.8M Safe, the "OP" led will be yellow and alarm will sound. For normal operating resistance of 1.8M Safe through 35M Safe, the "OP" led will be green. If the wrist strap resistance is higher than 35M High, "OP" led will be red and audible alarm will sound.

Table 1				
Resistance Setting	Typical Result			
1.8M LOW	Yellow - Alarm			
1.8M SAFE	Green			
35M SAFE	Green			
35M HIGH	Red - Alarm			

3. Repeat procedure with PVU plugged into OP2 (if applicable).

Work Station Verification Procedure

- 1. Plug the two test leads in the green inputs on the top of the CM2015PV and attach the alligator clips to the ends of the test leads.
- 2. Detach the Mat Ground Cord from the mat, and clip the alligator clip to the stud on the underside of the head of the cable.
- 3. Attach the other test lead to the snap on the mat.
- 4. To verify that the mats resistance limits, turn the dial of the CM2015PV to each designated resistance in Table 2 and record the constant monitor reaction. For normal operating resistance of 0Ω 100M Safe, the MAT led will be green. If MAT resistance is higher than 100M High, the Mat led will be red and audible alarm will sound.

Table 2				
Resistance Setting	Typical Result			
100M HIGH	Red Alarm			
All Other Values	Green			

6. Repeat procedure with the 2nd work surface if connected.

If the monitor did not pass as per the test procedure call Transforming Technologies at (419) 841-9552.





CM2015PV Instructions

Product Model: CM2015PV - Constant Monitor Verification Device

Threshold Resistance Test Results

Channel	Normal Va	nule	Standard	Error	Accurancy
10 Ω(SAFE)	9.000	Ω	9.027 Ω	0.027 Ω	0.30%
10Ω(HIGH)	11.000	Ω	10.990 Ω	-0.010 Ω	0.09%
100 Ω	100.000	Ω	99.400 Ω	-0.600 Ω	0.60%
1ΚΩ	1.000	ΚΩ	0.999 KΩ	-0.001 KΩ	0.10%
10K Ω	10.000	ΚΩ	9.983 KΩ	-0.017 KΩ	0.17%
750KΩ(LOW)	732.000	ΚΩ	727.827 KΩ	-4.173 KΩ	0.57%
750KΩ(SAFE)	768.000	ΚΩ	763.703 KΩ	-4.297 KΩ	0.56%
1.8MΩ(LOW)	1.590	МΩ	1.589 MΩ	-0.001 MΩ	0.06%
1.8MΩ(SAFE)	2.000	МΩ	1.999 MΩ	-0.001 MΩ	0.05%
10MΩ(SAFE)	9.000	МΩ	8.980 MΩ	-0.020 MΩ	0.22%
10MΩ(HIGH)	11.050	МΩ	11.024 MΩ	-0.026 MΩ	0.24%
35MΩ(SAFE)	33.300	МΩ	33.339 MΩ	0.039 MΩ	0.12%
35MΩ(HIGH)	36.640	МΩ	36.657 MΩ	0.017 MΩ	0.05%
100MΩ(SAFE)	90.000	МΩ	89.334 MΩ	-0.666 MΩ	0.74%
100MΩ(HIGH)	110.000	МΩ	108.840 MΩ	-1.160 MΩ	1.05%

Test Equipment: Name: Digital Precision

Model: Fluke 8846A

S/N: 9466014

Calibration Valid Date: 2018/7/12

Test Conditions: Temperature: $18^{\circ}\text{C} \sim 28^{\circ}$

Humidity: 55% ~ 65%

